



# Compatible Camera Lists for EGGPhoto360



### **Powershot A70, A75, A80, A95\***

Adapter : Canon LA DC 52D

### **Powershot A85\***

Adapter : Canon LA DC 52C

### **Powershot A520/510\***

Adapter: Canon LA DC 52F

EGG adapter ring: 52 to 46mm

### **Powershot G1, G2, G3, G4\***

Adapter: Canon LA DC 58

### **Powershot G5, G6, Pro1\***

Adapter: Canon LA DC 58B

EGG adapter ring: 58 to 49mm & 49 to 46mm

### **Powershot S30, S40, S45, S50\***

Adapter: CKC S30S40 AD

### **Powershot S60, S70\***

Adapter: LA DC 10

EGG adapter ring: 37 to 46mm

### **EX P600, EX P 700\*\***

Adapter : Casio LU 60A

EGG adapter ring: 58 to 49mm & 49 to 46mm

### **QV 2900UX\*\***

Adapter :

EGG adapter ring : 43 to 46mm

### **QV 3500, QV 5700\*\***

Adapter: Raynox RT52475

EGG adapter ring: 52 to 46mm

### **QV 4000\*\***

Adapter: Casio LU 35A.

EGG adapter ring: 55 to 49mm & 49 to 46mm



### **Photo PC 3000Z, Photo PC 3100Z\*\***

Adapter:

EGG adapter ring: 49 to 46mm

### **FinePix A-310, F-420, F-810\*\***

Adapter: HKDCPLUS

EGG adapter ring: 37 to 46mm

### **FinePix E-500, E-510\*\***

Adapter: AR FXE01

### **FinePix E-550\*\***

Adapter: AR FXE02

EGG adapter ring: 43 to 46mm

### **FinePix S-3000, S-3100\*\*, S-3800\***

Adapter: Fuji AR FX3

### **FinePix S-602\*\*, 4900\*\*, S-5000\*, S-5100\*\***

### **S-5500\*\*, 6900\*, 7000Z\***

Adapter: Fuji AR-FX9

EGG adapter ring: 55 to 49mm & 49 to 46mm



### **HP PhotoSmart 618, 735\*\***

Adapter: Tiffen adapter HP

EGG adapter ring: 37 to 46mm

### **HP PhotoSmart 850, 945\***

Adapter: Tiffen HP850AD

EGG adapter ring: 55 to 49mm & 49 to 46mm

### **HP PhotoSmart 912\*\***

Adapter:

EGG adapter ring: 49 to 46mm

\* Tested / Approved by our technical team

\*\* Compatible Theriotically, our technical team confirmed that will suit for egg lens

# Kodak

## Z730, Z760\*\*

Adapter: Kodak DX7630 / Z760

## Z740\*\*

Adapter: Kodak

## DX6340, DX7590, DX6490, Z7590\*\*

Adapter: Kodak DX6490 / DX7590  
EGG adapter ring: 37 to 46mm

## DX7440\*\*

Adapter: Kodak DX7440 / Z730

## DX7630\*\*

Adapter: Kodak DX7440 / Z730

EGG adapter ring: 37 to 46mm

## DiMAZE Series : 7, A1, A2, A200\*\*

EGG adapter ring: Not required

## DiMAZE Series : Z1, Z2\*\*

Adapter : ZCA 100

EGG adapter ring: 52 to 46mm

## DiMAZE Series : Z3\*\*

## DiMAZE Series : Z5\*\*

EGG adapter ring: Not required

## DiMAZE Series : Z10, Z20\*\*

Adapter: ZCA 200

EGG adapter ring: 52 to 46mm

## FineCam M400\*\*

Adapter: Raynox RT5249

EGG adapter ring: 52 to 46mm

## FineCam M410R\*\*

Adapter:

EGG adapter ring: 52 to 46mm



## CoolPix Series : 775\*

Adapter: Nikon UR E3

## CoolPix Series : 800, 885, 4300, 4500, 4600\*\*

Adapter: Nikon UR-E4 + UR-E7

## CoolPix Series : 880, 885, 4100, 4200\*\*

Adapter: Nikon UR-E2  
EGG adapter ring: 28 to 46mm

## CoolPix Series : 950, 990, 995\*

Adapter: Nikon UR-E7

## CoolPix Series : 5000\*

Adapter: Nikon UR-E5

## CoolPix Series : 5200, 5600\*\*

Adapter:

## CoolPix Series : 5400\*

Adapter: Nikon UR-E10

EGG adapter ring: 28 to 37mm & 37 to 46mm

## CoolPix Series : 5700, 8700\*

Adapter: Nikon UR-E12

## CoolPix Series : 8400\*\*

Adapter: Nikon UR E 14

EGG adapter ring: none

## CoolPix Series : 8800\*\*

Adapter: Adorama Metal 62

EGG adapter ring: 62 to 46mm

## EI200\*\*

Adapter: Tiffen Lens

## Optio MX, Optio MX4\*\*

Adapter:

EGG adapter ring: 37 to 46mm

## EI2000\*\*

Adapter:

EGG adapter ring: 49 to 46mm

# Panasonic

## Panasonic Lumix FZ1, Z2, Z3\*\*

Adapter:

EGG adapter ring: 52 to 46mm

## Panasonic Lumix Z4, Z5, Z10\*\*, Z20\*, Z15\*

Adapter: Raynox RT 5264P

EGG adapter ring: 52 to 46mm

## Panasonic Lumix Z7\*\*

Adapter: HKDC Panasonic DMC FX 7

EGG adapter ring: 37 to 46mm

## C700, C720, C730\*\*, C740, C750\*

## C765, C770\*\*

Adapter: CLA-4

EGG adapter ring: 55 to 49mm & 49 to 46mm

## C2100\*\*

EGG adapter ring: 49 to 46m

## C2500L\*\*

EGG adapter ring: 43 to 46m

## C3000Z, C3020Z, C3030Z\*\*

## C3040Z, C4000Z, C4040Z\*

Adapter: CLA-1

EGG adapter ring: 43 to 46mm

## C5000\*\*

Adapter: CLA-6

EGG adapter ring: 55 to 49mm & 49 to 46mm

## C5050, C5060, C7070\*\*

Adapter: CLA-7

EGG adapter ring:

## C8080\*

Adapter: CLA-8

EGG adapter ring: 58 to 49mm & 49 to 46mm

# OLYMPUS



# PENTAX

\* Tested / Approved by our technical team

\*\* Compatible Theriotically, our technical team confirmed that will suit for egg lens

**SONY**

**Cyber-shot Series : DSC - S60\*\***

Adapter: VAD PEB 30

EGG adapter ring: 30 to 37mm & 37 to 46mm

**S70\*\*, S75, S85\***

Adapter: VAD S 70

EGG adapter ring: 52 to 46mm

**S90\*\***

Adapter: VAD PEB 30

EGG adapter ring: 30 to 37mm & 37 to 46mm

**Mavica Series : MVC - CD200, CD250\*\***

Adapter: Raynox Lens

EGG adapter ring: 52 to 46mm

**CD300\*\*, CD400, CD500\***

Adapter: VDA S 70

EGG adapter ring: 52 to 46mm

**CD350\*\***

Adapter:

EGG adapter ring: 37 to 46mm

**CD1000\*\***

Adapter:

EGG adapter ring: 52 to 46mm

**Cyber-shot Series : DSC - F505V\*\*, F707, F717, F828\***

Adapter: none

EGG adapter ring: 58 to 49mm & 49 to 46mm

**Cyber-shot Series : DSC - V1\*\***

Adapter: Raynox RT 5245 VW

EGG adapter ring: 52 to 46mm

**SONY**

**TOSHIBA**

**Cyber-shot Series : DSC - V3\*\***

Adapter: VDA PHB 30

EGG adapter ring: 58 to 49mm & 49 to 46mm

**Cyber-Shot Series : W1, W5, W7\*\***

Adapter: VDA WA 30

EGG adapter ring: 30 to 37mm & 37 to 46mm

**Cyber-Shot Series : L1\*\***

Adapter:

EGG adapter ring:

**Cyber-shot Series : P100, P150\*\***

Adapter: VDA PHB 30

EGG adapter ring: 30 to 37mm & 47 to 46mm

**PDR Series : M70\***

Adapter: PDR AR52

EGG adapter ring: 43 to 46mm

**M71, M81\*\***

Adapter: M21 435 or Life TOSHM81

EGG adapter ring: 37 to 43mm & 43 to 46mm

**M500, M700\*\***

Adapter:

EGG adapter ring: 52 to 46mm

**M3300\*\***

Adapter: Life TOSH3300

EGG adapter ring: 43 to 46mm

**M4300\*\***

Adapter: Tiffen TOSH4300

EGG adapter ring: 43 to 46mm

\* Tested / Approved by our technical team

\*\* Compatible Theriotically, our technical team confirmed that will suit for egg lens